COOKTOP PARTS

For Model: GJP84902
(Black)

30" ELECTRIC RANGE
CERAN COOKTOP



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT9754172	Use & Care Guide
	LIT9782238	Wiring Diagram
	LIT9752776	Template, Anti−Tip
	LIT9752777	Installation Instructions
	LIT9781875	Service Instructions
2	9780939	Gasket, Cooktop Front & Sides
3	9781614	Rear Gasket
4	9750456PB	Frame, Cooktop
5	9753941	Support, Element
6	9752337GB	Back Splash
7	9753675	Brace, Support
8	9753691	Support Clips (4)
9	9780771	Bumper−White (4)
10	9781935	Hot Light
11		Element, Surface
	8272564	1500W − LR
	8272563	1000/2400W − LF
	9753999	Bridge Element
	9754274	Warm Zone
12	9754255CW	Cooktop, Ceran
15	9781460	Rod, Small Ceran Element
17	9781235	Speed Clip
18	9781459	Rod, Large Ceran Element
19	9753040CB	Cover Vent
20	3149190	Clip, Mounting
	9753677	Spring, Warm Zone
23	3149333	Screw, 10−16 x 1/2
24	423248	Screw, 10−16 x 3/4



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: GJP84902

(Black)



Illus. No.	Part No.	DESCRIPTION
1	9752431PB	Lamp Cover
2	9754226	Console−Glass (Control Panel)
3	3191072	Breaker, 15Amp. (2)
4		End Cap
	9752422FB	Left
	9752423FB	Right
5	9780577	Button, Plug (2)
6	3191070	Panel, Control
7	9780852	Screw, 10−16 x 3/8
8	9752405FB	Knobs, Control (4)
9	313102	Light, Indicator (2) (Burners)

Illus. No.	Part No.	DESCRIPTION
10	9752854	Spacer, Glass
12	9752443PB	Trim Strip
13	9754017FB	Switch, Rocker
14	9751480FB	Outlet, Untimed (2)
15	9754261	Timer
16	9781954FB	Knob, Timer (19)
17	9753304	Bracket (2)
18	9780265	Screw, 10−16 x 3/8
19		Infinite Switch
	9750643	1500W
	9750644	1800W
	9755174	Dual, (2)
20	3400816	Screw, 8−32 x 3/16

Illus. No.	Part No.	DESCRIPTION
21	9782259	Receptacle, Light
22	9750866	Starter, Holder
23	9781118	Starter, Light
25	422581	Light, Fluorescent
28	9753017	Clip, Spring (2)
29	9752589	Lens, Light (2)
30	9752439	Base, Console
31	3196168	Screw, 8−18 x 1/2
32	9753076FB	Insert
	9750995	Insulation, Control Panel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: GJP84902
(Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: GJP84902
(Black)

Illus. No.	Part No.	DESCRIPTION
2	9782003PB	Trim, Door−Left
3	9782004PB	Trim, Door−Right
4	9781209PB	Trim, Door Bottom
5	9781635PB	Glass, Door Front (Black)
6	9753498GB	Vent, Door
	9781659	Gasket, Door Vent
8	9751136PB	Handle, Door
9	9781449	Gasket, Door Glass
10	9782033	Hinge, Door R or L
12	9781602	Frame, Glass
13	9781586	Shield, Door
14	9780771	Bumper, Door
15	9781593	Glass, Pyro (2)
16	9755177	Seal, Window
18	9754006	Insulation, Door
19	9781600GM	Liner, Door
20	9750257	Drawer & Roller
21	9750169	Bracket, Drawer
22	422604	Roller, Drawer
23	9750676	Retainer, Door
24	9782108PB	Front, Drawer
25	9750693	Heat, Channel
26	9751248	Latch, Drawer
27	9780806	Screw, 4−24 x 3/8
	90296	Clip
28	9781502	Spacer, Door (8)
29	9780265	Screw, 10−16 x 3/8
30	9781072	Screw, 10−14 x 3/8

OVEN CHASSIS PARTS

For Model: GJP84902

(Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Model: GJP84902
(Black)

Illus. No.	Part No.	DESCRIPTION
1	9750146	Main Chassis, Back
2	9750514GM	Chassis, Front
3	9754003	Insulation, Wrap
4	9754011	Insulation, Rear
5	9754263GM	Oven Liner
6	9755179	Gasket Oven
7	9781907PB	Oven, Side Panel
8	9780881	Ballast
9	9780664	Shield, Insulation
10	9781580	Door Switch (Oven Light)
11	9750478	Burner Box
13	9750523	Rod, Lock
14	9750150	Panel, Rear
15	9750223	Drawer Rail, Left
	9750224	Drawer Rail, Right
16	9780265	Screw, 10−16 x 3/8
17	9750147	Bottom Rail (2)
18	312701	Foot, (4)
19	9782005	Receiver, Hinge (R or L)
20	9781904	Support Rail, Pan (2)
22	9750258	Hinge, Cktp.−Left
	9750416	Hinge, Cktp.−Right
23	9782257	Oven Lock Assembly
25	9753091	Vent Tube
27	9782117	Switch, Interlock
28	9780578	Plug, Button
29	258076	Block, Terminal
30	9750767	Gasket, Vent
31	9750393	Cover, Vent
32	9750394	Back, Vent
33	9780272	Screw, 10−16 x 1/2
36	9750887	Screw, 4−40 x 1
37	9750888	Nut
38	98884	Screw, 10−16 x 1
39	112432	Nut
	9754253	Insulation, Burner Box Rear

OVEN PARTS

For Model: GJP84902

(Black)



Illus. No.	Part No.	DESCRIPTION
1	9750211	Element, Broil
2	340184	Screw, 10−16 x 1.5
3	8935	Bulb, Oven
4	9781050	Light Socket
5	420104GM	Grill, Broiler
6	420101GM	Pan, Broiler
7	9750498	Rack, Standard (2)
8	9782081	Sensor
9	9780265	Screw, 10−16 x 3/8
10	9781049	Lens, Light
11	3184533	Gasket, Lens
12	9781509	Screw, 8−32 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

HIDDEN BAKE PARTS

For Model: GJP84902

(Black)



Illus. No.	Part No.	DESCRIPTION
1	9752294	Element, Bake
2	9782048	Pan, Hidden Bake
3	9782049	Cover, Hidden Bake
4	9754005	Insulation
5	9752735	Retainer, Insulation
6	9782050	Plate, Reflector
7	9782051	Shield
8	9780265	Screw, 10−16 x 3/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Model: GJP84902
(Black)

Illus. No.	Part No.	DESCRIPTION

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150°c
242820	Wire, Black 14 Ga. 150°c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242829	Wire, Red 12 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242826	Wire, White 14 Ga. 150°c
242827	Wire, Yellow 14 Ga. 150°c
242832	Wire, Yellow 14 Ga. 200°c

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean (1/2 Pt.)
261582	Grease
9780196	Cleaner

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")
241430	Foil, Aluminum Oven (18" x 25')

WIRING HARNESS PARTS

9782132	Harness, Wire (Main)
9753682	Harness, Wire (Cooktop Ceran)
9752772	Harness, Wire (Top Light)
9753683	Harness, Wire (Hidden Bake)
9750744	Harness, Wire Door Switch
9754100	Harness, Wire (Bridge Element)
9753680	Harness, Wire (Warm Zone)
9781287	Power Cord
690989	Screw, Grounding
9781903	Jumber, Bake/Broil
9750984	Hanger, Wire
9781291	Harness, Outlet (2)
20082084	Tie, Wire
9780585	Guard, Wire
9782139	Harness, Wire (Cooktop Control)